


To Un-Foldit




With wheels and legs on ground, press the release button



Place cart on end as shown, then extend handles.




Tilt cart to right or left, then pull legs outward.




Slide front gate into place, and the cart is ready.


To Foldit




Remove front gate and store on side of cart.



2 To collapse, pull handles inward while pushing floors outward, at the same time.



3 Tilt cart right of left, and compress inward to fold.



A. Press release button.
B. Push handles down until locked.